


## Instructions for setting up the MiPro PA system



Here is where you will find the mains lead and cable for tethered microphone.



Here is where you will find the two hand-held microphones.

The two radio mics both need 2 AA batteries.


1. Plug cable microphone in here.

2. Turn on here

3. Turn on cable mic and test volume. Adjust as necessary with marked control.

4. Turn on hand-held radio mic and test volume. Adjust as necessary with marked

5. Turn on tie/lapel radio mic and test volume. Adjust as necessary with marked control. Check this again with the speaker on arrival.



The PA should be set on the special stand so that it is above head level of the audience. (Approx 2m) You may need help lifting to this height – take care.

Remember to avoid microphones being directly in front of the PA so as to avoid feedback.

Sorry if this is teaching granny to suck eggs. Hope all goes well.

Richard